

# DSC® Power832® Security System



## Up to 12 Keypads

- up to 8 hardwired keypads and 4 wireless keypads
- 4 hardwired keypads available *with zone input*...
  - PC5508Z eight zone LED keypad
  - PC5516Z sixteen zone LED keypad
  - PC5532Z thirty two zone LED keypad
  - LCD5500Z alphanumeric keypad
- WLS910... wireless handheld keypad
- added wireless control is provided by ...
  - WLS908... wireless panic pendant
  - WLS909... wireless key

## 32 Zones Hardwired or Wireless ... 2 Partitions

### Hardwired

- 8 zones on main panel
- PC5108 - 8 zone expansion module
- PC5108L - 8 zone expansion module *plus* Downlook video on Power832 PC5015 panel
- PC5700 *...Canada only* - 4 general purpose zones, 2 waterflow zones, 1 ground fault zone, *plus* dual supervised telephone lines
- PC5720 *...Canada only* - 5 general purpose zones, 2 waterflow zone, 1 ground fault zone, *plus* printer or DVACS communications

### Wireless

- PC5132 - 32 zone wireless zone expansion module

## 14 PGM Outputs

- up to 5 high current outputs... 1 on main panel *plus* :  
PC5204 - 4 output high current power supply module
  - 1 output fully supervised for siren output
- up to 9 low current outputs... 1 on main panel *plus* :  
PC5208 - 8 low current output module

## Advanced Communications

- supports all major formats including SIA and Contact ID
- LINKS1000™ cellular communication
- LINKS2150™ and LINKS2450™ long range radio communication
- DVACS communication using PC5400 or PC5720 modules
- Downlook video transmission using PC5108L module on Power832 PC5015 main control panel
- event initiated personal paging
- 3 phone numbers (3rd backs up primary number)
- 2 account numbers

## Integrated Intercom Audio

- supports Central Station Two Way Voice and Home Intercom features using PC5928 audio interface module, PC5921 intercom stations, and PC5904 two way listen-in stations

## Integrated CCTV

- supports Downlook still frame video transmission using PC5108L module on Power832 PC5015 main control panel
- provides local VCR/monitor video switching for 8 cameras

## Integrated Voice Assisted Security & Home Automation

- Escort5580 & 5580TC provide voice assisted security *and* automation control for up to 32 X-10 devices *plus* thermostat control on 5580TC

## Efficient Installation

- 4 wire communications bus (KEYBUS)
  - connect modules up to 1000' (305m) from control panel
  - PC5204 - 4 output high current power supply module provides up to 1A auxiliary power
  - main panel provides up to 550mA auxiliary power

- PC5010 main control panel - alarm only
- PC5015 main control panel - alarm plus Downlook video capability
- support up to 32 zones using any combination of up to :
  - 8 hardwire zones on main panel
  - 8 hardwire zones using PC5108L video matrix module  
*(on PC5015 only)*
  - 4 general purpose hardwire zones and 2 waterflow hardwire zones using PC5700 fire module *(in Canada only)*
  - 24 hardwire zones using PC5108 eight zone expander modules
  - 8 keypad zones
  - 32 wireless zones using PC5132 wireless receiver module
- zone programming
  - all zones programmable as burglary or fire
  - zone options include : Normally Closed loop, Single End of Line (EOL) resistor, and Double EOL resistor<sup>(1)</sup>  
*(1) keypad zones cannot be programmed as fire zones and cannot support Double EOL resistor supervision*
  - 27 programmable zone types, 8 programmable zone options
- audible alarm output
  - supervised bell output - 700mA @ 12VDC, PTC protected, current limited at 3A
  - steady, pulsed, temporal pattern, or strobe fire output
  - additional supervised siren output is available using PC5204 power supply module
- programmable voltage outputs
  - 1 high current 300mA PGM... can also be used for 2 wire smoke with a maximum of 20 detectors at 15mA per detector
  - 1 low current 50mA PGM
  - 8 additional low current PGM outputs using PC5208 module
  - 4 additional high current PGM outputs using PC5204 module
  - 24 programmable options
- local PCLINK™ and remote upload/download capability
  - program system using DLS software and direct PC connection to control panel or via remote PC over telephone line
  - view status and trouble conditions, and system 128 event buffer
  - remote access can be controlled by owner to prevent unauthorized access to system
- power supply
  - 550mA @ 12.5VDC auxiliary power (400mA for UL applications)
  - positive temperature coefficient (PTC) protected battery, AUX, and Bell output
  - electronic protection of KEYBUS
  - supervision of AC power loss, low battery, auxiliary power failure
  - internal clock locked to AC power frequency
- EEPROM memory
  - will not lose programming or system status on complete AC and battery failure
- digital communicator
  - supports all major formats including SIA & Contact ID
  - supports LINKS1000™ cellular communications
  - supports LINKS2150™ and LINKS2450™ long range radio communications
  - 3 phone numbers (3rd backs up primary)
  - 2 account numbers - DTMF or pulse dialing
  - DPDT line seizure - anti-jam feature
  - split reporting of selected events to each telephone number
  - event initiated personal paging
- battery required : 12V, 4Ah, rechargeable sealed lead acid
- transformer required : 16.5VAC, 40VA

## System Operation

- 2 system partitions... 2 account numbers
  - each partition acts as a separate alarm system with any number of zones, user codes, keypads and individually programmable features
- 38 - 4 or 6 digit access codes
  - 32 user codes, 1 system master code, 2 partition master codes, 2 duress codes, and 1 maintenance code
- automatic arming by partition
  - each partition may be programmed to auto-arm at its own time each day
- keypad lockout
  - panel can be programmed to lockout keypad if a series of incorrect access code entries are made
- 'quick arm' and 'quick exit'
  - allows users to arm and exit easily
- 'stay/away' zones and 'stay' arming
  - security of perimeter arming while premise is occupied
- door chime
  - programmable by zone
  - monitor a door by having keypad beep when the door is opened and again when door is closed
- 128 event buffer
  - all events automatically stored with time and date stamp to buffer
  - events can be printed on-site using the PC5400 serial printer interface module, viewed through an LCD Keypad, or viewed and printed via PC using DLS software

## Full Supervision

The system continuously monitors the following trouble conditions :

- AC power failure
- fire trouble
- low battery
- loss of internal clock
- fail to communicate
- module fault (supervisory or tamper)
- camera troubles *(on PC5015 with Downlook)*
- trouble by zone
- telephone line trouble
- bell output trouble
- tamper by zone
- aux power supply fault

## False Alarm Prevention Features

- audible exit delay
- quick exit
- swinger shutdown
- recent closing transmission
- double hit timer\*
- rotating keypress buffer
- audible exit fault
- urgency on entry delay
- cross zone alarm
- burglary verified timer\*
- communication delay
- arm/disarm bell squawk

*\* on PC5015 v2.2x and higher*

## LCD5500Z Plain Language Keypad



The Power832 security system is fully programmable from the attractive, easy to use dual-language LCD5500Z keypad :

- connect up to 8 keypads, combination LED and/or LCD
- zone input
  - connect detector to keypad to avoid separate wiring back to panel
- multi-language (*languages vary according to country*)
  - simple key entry to toggle between languages while viewing keypad
- rotating keypress buffer reduces access code entry false alarms
- large 32 character display
  - zone identification
  - system instructions
  - system status
  - 128 event buffer
  - trouble conditions
- plain language operating instructions
  - menu for user functions
  - what key to press for specific functions
  - steps for programming functions
- automatic scrolling of alarms in memory
  - scrolls through alarms in memory while keypad is idle
- 12 hour or 24 hour clock display
- 5 programmable function keys with 25 options such as Home Arm, Away Arm, Quick Exit etc.
- 4 keypad-activated alarms : Fire, Auxiliary, Panic, and Duress
- 3 LED indicators : Ready, Armed and Trouble
  - allow system status to be viewed at a glance
- backlit display
  - display and keys backlit for easy viewing in low light conditions
  - adjustable brightness and contrast
  - *Backlighting Boost* provides extra high key lighting when any key is pressed
- piezo buzzer
  - provides audible feedback for correct key entries, pre-alert, and system trouble status
  - adjustable buzzer tone
- connect to 4 wire KEYBUS up to 1000' (305m) from control panel
- specifications
  - current draw : 85mA with backlighting boost
  - dimensions : 5.75"W x 4.5"H x 1"D (144 x 114 x 25mm)

## LED Keypads



The Power832 system is fully programmable from any of the attractive, easy to use, LED keypads :

- 3 keypads available :
  - PC5508Z ..... 8 zone LED keypad
  - PC5516Z ..... 16 zone LED keypad
  - PC5532Z ..... 32 zone LED keypad
- zone input
  - connect detector to keypad to avoid separate wiring back to panel
- rotating keypress buffer reduces access code entry false alarms
- 5 programmable function keys with 25 options such as Home Arm, Away Arm, Quick Exit etc.
- LED indicators : Ready, Armed, Trouble, Memory, Bypass, Fire, Program
- 4 keypad-activated alarms...Panic, Auxiliary, Fire, and Duress
- backlit display...with *Backlighting Boost* to provide extra high key lighting when any key is pressed
- piezo buzzer...provides audible feedback for correct key entries, pre-alert, and system trouble status... with adjustable buzzer tone
- connect to 4 wire KEYBUS up to 1000' (305m) from control panel
- specifications
  - current draw : 85mA with backlighting boost
  - dimensions : 5.75"W x 4.5"H x 1"D (144 x 114 x 25mm)

## PC5400 - Printer Interface Module



- both PC5400 and PC5400DV may be used at the same time on a system
- provides RS232 serial printer connection for report of events logged to the system event buffer... prints event, partition, time, and date that event occurred
- supports any 300, 1200, 2400 or 4800 BPS serial printer
- connect printer up to 200' (61m) from PC5400
- connect PC5400 up to 1000' (305m) from control panel via KEYBUS
- current draw : 65mA @ 12VDC
- maximum one module per system

832

## PC5400DV - DVACS Interface Module

- both PC5400 and PC5400DV may be used at the same time on a system
- provides ULC Level 3 Line Security.
- provides full DVACS reporting of all system events.
- module is pre-programmed to SIA zone definitions
- events simultaneously communicated via DVACS and other installed communications mode such as digital or cellular
- full cross supervision between the system control panel and the DVACS module e.g... problems with one will be communicated to the central station by the other.
- central station requires Sur-Gard receiver with DVL2A version 2 or higher software.
- complete with 8 pin jack, and communications and power cables for connection to F1/F2 subset.
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 65mA @ 12VDC

832

## Hardwired Expansion

832

### PC5108 - 8 Zone Expansion Module

- adds 8 hardwired general purpose burglary or fire zones
- provides 100mA @ 12VDC auxiliary current, PTC protected
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 35mA @ 12VDC

832

...Canada only

### PC5700 Fire Zone Expansion Module

- a zone expansion module which provides :
  - dual supervised telephone lines
  - 2 Class A supervisory waterflow zones
  - ground fault detection zone
  - 4 general purpose fire or burglary zones
- tamper and trouble reporting codes
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 150mA @ 12VDC

832

...Canada only

### PC5720 Fire / Printer / DVACS Module

- a zone expansion module which can also be used to provide either a serial printer or DVACS communications interface
- 8 zone inputs include :
  - 2 Class A supervisory waterflow zones
  - ground fault detection zone
  - 5 general purpose fire or burglary zones
- as RS232 printer interface :
  - baud rates... 300, 1200, 2400, 4800
  - connect printer up to 200' (61m) from the PC5720 module
- as DVACS interface :
  - provides ULC Level 3 Line Security.
  - provides full DVACS reporting of all system events.
  - module is pre-programmed to SIA zone definitions
  - events simultaneously communicated via DVACS and other installed communications mode such as digital or cellular
  - full cross supervision between the system control panel and the DVACS module i.e... problems with one will be communicated to the central station by the other.

- central station requires Sur-Gard receiver with DVL2A version 2 or higher software.
- complete with 8 pin jack, and communications and power cables for connection to F1/F2 subset.
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw @ 12VDC : 80mA standby, 100mA with printer, 120mA with DVACS

832

## Wireless Expansion

832

### PC5132 Wireless Receiver



- add up to 32 DSC wireless detectors\* including :
  - WLS904 ..... passive infrared detector
  - WLS906 ..... photoelectric smoke detector
  - WLS907 ..... slim-line transmitter
- \* devices use standard Eveready Energizer® alkaline batteries
- 900 MHz true 'Spread Spectrum' technology, fully supervised for communication integrity
- easy sensor enroll process
- supervisory transmissions every 12 minutes
- programmable 1-24hr supervisory window
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 130mA @ 12VDC

832

## Wireless Control Devices



### WLS908 Wireless Panic Pendant

- communicates a non-medical alarm to central station
- 32 pendants maximum...each occupying 1 alarm zone
- sealed non-replaceable battery

### WLS909 Wireless Key

- remote arm/disarm control
- up to 16 keys per system
- 3 photo/electronic 1.5V batteries included

### WLS910 Wireless Hand-Held Keypad

- personal remote keypad
- up to 4 wireless keypads per system (in addition to hardwired keypads)
- 3 'AAA' batteries included

832

## Integrated Voice Assisted Security & Home Automation



832

### ESCORT 5580 Voice Assisted Security & Automation Control Module

- turns any touch-tone phone into a fully functional keypad with Global and Partition control
- built-in power line interface for control of 32 X-10 automation control devices
  - 16 schedules with On Time, Off Time, and Day of Week
  - 8 user controlled automation modes
  - full range of dimming levels for lighting control
  - event activated control for any PGM output supported by the main panel
- an extensive library of voice prompts for security and automation operation, programming, and system status feedback
  - 250 system words for pre-programmed system functions
  - 240 word library for user programmable voice prompts for Automation Item Labels, Automation Mode Labels, Partition Labels, and Zone Labels
- program up to 6 words per voice label
- powerful 'say number' command can announce numbers from 0-999 in three different ways
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 150mA @ 12VDC


832

### ESCORT 5580TC

- all the features of the Escort 5580 *plus* thermostat control
- supports up to *four* EMS-100 thermostats
- EMS-100 has 4 temperature control modes :
  - day occupancy mode                      - night occupancy mode
  - auxiliary occupancy mode                - away occupancy mode
- each thermostat optionally supports :
  - up to six EMS-IDS remote indoor temperature sensors for interior temperature averaging
  - one EMS-ODS outdoor temperature sensor for display of outdoor temperature

832

## Integrated Intercom Audio Interface



832

### PC5928 Audio Interface Module *with* PC5921 Series Intercom Stations & PC5904 Two Way Listen-In Stations



#### PC5921 Internal Intercom Station

*also available :*

PC5921EXT...external intercom station

PC5921EXT/R...external intercom station with relay for operation of existing door bell

- PC5928 Audio Interface Module
  - provides 7 output ports for connection of PC5921 Series Intercom Stations
  - connect up to 1000' (305m) from control panel via KEYBUS
- local intercom functions :
  - page/answer                      - do not disturb
  - doorbell function                - door strike release
- listen-in broadcast ...allows any station to be programmed as a 'broadcast station' to which all other internal stations in the system may listen in
- programmable as sounder for fire/burglar alarms
- answer telephone calls received on regular voice line
  - ringing programmable by station
  - supports call waiting
  - allows call transfer to in-house phones
- audio user help
  - provides plain language prompts for system programming, operation, and system status reports when installed with Escort 5580 Voice Prompt Module and keypads mounted with PC5921 Intercom Stations
- PC5904 central station 2-way listen-in station
  - programmable control tones (from central station)
  - select zone, listen/talk, extend on-line time, hang up

832

## Integrated CCTV




832

## PC5108L Downlook Interface Module

\*\*\*for PC5015 only\*\*\*

- provides an interface between the PC5015 alarm control panel and the Downlook DLM-4 still frame video transmission module
- communicates alarm followed by video over a single telephone line in one transmission to a Sur-Gard MLR2 digital receiver
- 8 inputs for video cameras, VCRs, or video switchers
- 8 general purpose burglary or fire alarm zone inputs
- any alarm zone (up to 32) or group of zones can be programmed to initiate video capture of 4 frames from any 4 sources - in any sequence
- programmable on-site sequential video switcher mode
  - view and capture images on a monitor / VCR setup
  - select cameras for viewing manually using an LED keypad or program system to switch automatically between selected cameras at programmed dwell times
- supervised by main panel
- programmable via downloading using modem or direct PC-Link
- connect up to 1000' (305m) from control panel via KEYBUS
- module current draw : 60mA @ 12VDC



832

## PGM Output Expansion

832

## PC5204 Power Supply / High Current Output Module

- provides 1A @ 12.5VDC auxiliary power for additional modules and devices
- includes 4 fully programmable high current outputs
  - rated at 1A @ 12VDC, PTC protected
  - will provide 3A short term if battery backup connected
  - each output can sink up to 3A
- output #1 may also be used as a supervised bell output
  - 700mA max
- each output programmable to activate for any of 24 options
- connect up to 1000' (305m) from control panel via KEYBUS
- fully supervised for : tamper, low battery, AC power loss, and auxiliary power trouble
- maximum 1 module per system
- module current draw : 20mA @ 12VDC
- battery required : 4Ah minimum
- transformer required : 16.5VAC, 40VA

832

## PC5208 Low Current Output Module

- module provides 8 low current transistor switch outputs
  - each output can sink up to 50mA
  - up to 250mA max at one time
- each output programmable to activate for any of 24 options
- connect up to 1000' (305m) from control panel via KEYBUS
- fully supervised for tamper
- maximum 1 module per system
- module current draw : 20mA @ 12VDC

— Note —

Power832 Engineer's Specifications are available on :

- separate copy
- DSC's web site '[www.dscgrp.com](http://www.dscgrp.com)'

**DSC**<sup>®</sup>  
Security Products

Digital Security Controls  
1645 Flint Road, Downsview, ON, Canada M3J2J6  
[www.dscgrp.com](http://www.dscgrp.com)